

MS9520 Voyager® and MS9540 VoyagerCG™ Addendum

Metrologic's MS9520 Voyager and MS9540 VoyagerCG laser scanners now have the ability to decode RSS bar codes. This software addendum enables either unit with software #14810 and higher to be programmed to scan RSS type codes as it would any other symbology.

Manufacturers Note:

XT keyboard will no longer be supported in standard software releases with software #14810 or higher. If XT keyboard is needed for your application, software #14806 or lower is required, contact a Metrologic customer service representative at 1-800-ID-METRO for further assistance.

RSS BAR CODE IMPLEMENTATION

Default parameters are marked with an (*).

When scanning RSS bar codes, it is recommended that double border requirements be enabled because of the large spaces often found in RSS symbologies.



RSS 14 BAR CODES

The following bar codes are used to enable/disable RSS 14 features.

Enable RSS 14



* Disable RSS 14



* Transmit
RSS 14 Check Digit



Do Not Transmit
RSS 14 Check Digit



November 2001
Printed in the USA



00 - 02871

* Transmit RSS 14
Application ID



Application Identifier "01"
is transmitted by default.

Do Not Transmit
RSS 14 Application ID



* Transmit RSS Limited
Application ID



Application identifier "01"
is transmitted by default.

Do Not Transmit RSS
Limited Application ID



* Transmit RSS 14
Symbology ID



Symbology Identifier "je0"
is transmitted by default.

Do Not Transmit RSS 14
Symbology



* Transmit RSS Limited
Symbology ID



Symbology identifier "je0"
is transmitted by Default

Do Not Transmit RSS
Limited Symbology ID



RSS LIMITED BAR CODES

The following bar codes are used to enable/disable RSS-limited features.

Enable RSS Limited



* Disable RSS Limited



Enable RSS Expanded



* Disable RSS Expanded



* Transmit
RSS Limited CD



Do Not Transmit RSS
Limited CD



* Transmit RSS Expanded
Symbol ID



Symbology identifier "je0"
is transmitted by default

Do Not Transmit RSS
Expanded Symbol ID

