


● Calibration and setup (SETUP) function:

After entering into calibration and setup (SETUP) function, the tester shall display as follows:



```
-----SETUP-----
->UNIT: Meter
CALIBRATION
QUIT
```

Push **▲▼** key to move cursor “->” indicator up and down to the desired item and then push **PAIR&||** key to enter related setup function accordingly.

UNIT: It is used to set up length unit and shifts between meter (Meter) and feet (FT).

CALIBRATION is calibration function. (Detailed as related chapters hereinafter)

QUIT is used to return the main menu.

Preface

Network Cable Tester is a powerful special tool to prevent and solve cable installation problem. Network Cable Tester is the best choice to verify any speech and data cable installation procedure. The tester is capable to have a number of tests such as cable connection sequence, length, user jumper and cable connection continuity and determine any open circuit, short circuit, jumper or cross-talk interference. It is a useful tool to reduce cable installation cost and save cable installation time.